


# EASYSTOP Wireless Bell Push System




- 10.**68301** Remote Push Button. Grey Body Red Button.
- 10.**69551** Remote Push Button. DISABLED. Grey Body Blue Button.


**Easy Stop** is a new system placed on citybuses, composed of control unit which, by receiving an impulse from a microphone activated by an ultra-sound push-button, generates a signal that can be used for asking the bus to stop.



Microphone



Control Unit



- 10.**68321** Processing Unit Kit.

